





USER MANUAL
AX440 BLUETOOTH SPEAKER

100%
Satisfaction
Guaranteed


To activate the 1-year warranty on your Bluetooth Speaker, visit <http://www.alpatronix.com/> and click on the warranty link to register your product by filling out a quick and easy form. The Alpatronix warranty will fully cover your purchase against all defects in material and/or workmanship for an entire year. Most return policies only allow returns for a period of 14 – 30 days from the date of purchase, so hurry and register your product to give yourself peace of mind knowing Alpatronix has got you covered for a whole year.



- 1 Previous Track (click) / Volume Down (hold)
- 2 Functions (Aux/USB/Bluetooth)
- 3 Play / Pause
- 4 Next Track (click) / Volume Up (hold)



- 5 ON / OFF
- 6 Power input
- 7 USB flash input
- 8 AUX input



Technical Specification

Bluetooth Version 4.1
 Transmission Distance: < 30ft (10m)
 Battery Capacity: 5400mAh
 Output Power: 15 watts x 2 = 30 watts
 Frequency Response: 20Hz - 20KHz
 S/N Ratio: >60db
 THD: <0.2%

LED Reference Guide

Mode	Status	LED Indicator
AUX	Play / Pause	RED (solid)
Bluetooth	Waiting for pairing Play Pause	BLUE (blinking fast) BLUE (blinking slowly) BLUE (solid)

Step I

Register Your Product

Register your product and benefit from the 1-year warranty. It's quick and easy.

Most return policies only allow for a defective product to be returned within 14 – 30 days after the date of purchase... and most issues that happen due to defects in material and workmanship have a knack of happening after this return period has ended. We have seen the sad-puppy look on customers' faces for too long and understand how upsetting it is to spend your hard-earned dollars on something that stops working after a few weeks! That's why Alpatronix's Ironclad Warranty will protect you for a whole year against all defects in material and/or workmanship. So register your product by visiting www.alpatronix.com, and click on the "Warranty" on the top menu to register your product and activate your warranty. Rest easy that you are covered no matter what the return policy is where you purchased your product!

If you have a defective product and need us to take care of you, email us at support@alpatronix.com and rest assured that our support team will make this a quick and easy process with as little pain as possible.


Notice:

Alpatronix warranty is only valid when you purchase from authorized sellers, and only within the country in which you purchased the product. If you are not sure whether the retailer you are purchasing from is an authorized retailer, please contact us and we will be happy to further assist you. Alpatronix sells directly on Amazon.com, and on the Alpatronix.com website. Alpatronix warranty does not cover user damage. Tampering with your device or user damage also voids the manufacturer warranty.

Step II

Turn the speaker on


- Charge the speaker with AC adapter included. The built-in lithium battery may need to be charged. It is always recommended to charge any electronic device for about 24 hours before first time use.
- Turn the ON / OFF switch (5) to ON position. The LEDs on the front control panel will turn on.
- If you have already paired the speaker to a device before, the speaker will automatically detect and pair with the last device it was paired with (as long as that device has its Bluetooth turned on and is within range). If you have not paired the speaker to any device yet, follow the instructions in the pairing section.



Step III

Pair the speaker to your iPhone or Smart Device

- Press the Functions button (2) to place the speaker into Bluetooth mode. The LED will turn BLUE when in Bluetooth mode. If the speaker has not paired with any devices before, the LED will be flashing rapidly. If/when the speaker is paired to a device, the LED will flash every two seconds.
- To disconnect from a previous device and pair to a new device, press and hold the “▶||” button (3) until the LED begins to flash rapidly.
- On your iPhone or any other Bluetooth enabled device, tap “Settings” “General” “Bluetooth”.
- Make sure your iPhone or other smart device’s Bluetooth is turn ON.
- Find “AX440” on the list of available devices, and tap to pair.
- No password is required for most devices, but if prompted, enter “0000” to pair.



Note: Pairing with computers and laptops

The AX440 will pair easily with any Apple device including Mac computers and laptops. For pairing with PC computers, please refer to your device's user manual, or download a compatible Bluetooth driver. Bluetooth driver compatibility varies depending on the type of PC computer or laptop you own, so Alpatronix Customer Service staff would not be able to help identify an appropriate driver. When searching for an appropriate driver, look for one that supports A2DP and AVRCP standard profiles.

Step IV

Operation

- To play music, press the “▶||” button (3). To pause, press the button again.
- To increase the volume, press and hold the “+” button (4). To decrease the volume, press and hold the “-” button (1).
- o On Apple iPhone and iPad, the speaker and phone volume adjust together. On other devices this operation depends on the device's software. To hear the speaker at max volume, you may need to raise the volume to max both on your phone as well as the AX440.
- To skip forward, tap the “+” button (4). To skip back, tap the “-” button (1).
- To play using AUX 3.5mm jack, simply connect the AUX cable to your phone/device and connect to the speaker's AUX input (8), then press the Function button (2) until the speaker enters AUX mode. When in AUX mode, the LED will glow RED.

o Please note that play/pause, and skip forward/back buttons of the speaker will not work when the speaker is connected via AUX cable. You will need to control those functions directly through your phone or streaming device. Pressing the play/pause button will simply mute the speaker.

o When connected via AUX, the speaker will automatically disconnect from any Bluetooth device it is paired with.

Notes:

- You only need to perform Step III (Pairing) for the initial setup. After the first successful connection, the speaker will connect automatically to your device whenever you turn the power on.
- If you need to connect the speaker to a different device, simply press and hold the play/pause button to disconnect from the first device and force the speaker into pairing mode again, then pair with the second device. Alternatively, you can find the speaker on your phone's list of trusted devices, and delete it from the list. When the AX440 cannot find the last device it was paired with, it will enter pairing mode again automatically.

Caring for your AX440

To extend the life of your AX440, please note the following

- Avoid contact with water, moisture, or extreme humidity. The AX440 is not water resistant or waterproof.
- Avoid exposure to extreme temperatures (hot or cold), or exposure to fire or any other heat source.
- Clean the product using a dry and soft cloth.
- If you intend to store the product longer than 3 months, please ensure the battery has at least a 50% charge. Always fully charge the battery again after long-term storage and before use. Store the product in its carrying pouch, in a dry environment, and away from extreme temperatures.
- Please only use the charger provided with the product. If you need additional charging cables, please contact Alpatronix for further assistance.
- Do not attempt to fix the product, or to open or disassemble it. It will void the manufacturer's warranty and expose you to risk of severe injury or electric shock. In case of any malfunction, please contact Alpatronix Customer Service for further assistance.

Troubleshooting

If you are unable to connect the speaker to your device, follow the steps below

- Check if the battery is low. When the battery is low, the speaker may have trouble connecting. Charge the battery fully and try again.
- Check the power switch and make sure it is on.
- Restart the speaker. Turn the power OFF and then turn it back ON again.
- Make sure the Bluetooth on your device is enabled.
- Try removing the pairing by going to the Bluetooth section of your device, choose AX440, and select "Forget this Device" (for Android devices: select "Unpair"). Turn Bluetooth off for 3 seconds on your device, and turn it back on. Repeat Step III to attempt to pair again.

Please remember that your product comes with a 1-year warranty. If there is any problem with your product, please do not hesitate to contact us.
PO Box 17070, Anaheim, CA 92806
United States of America
(888) 407 - 7515
support@alpatronix.com